
HP Pavilion dv6500 Speaker Replacement

This guide will help users replace the speaker of their laptop


Written By: Andrew



TOOLS:


- Phillips #00 Screwdriver (1)


Step 1 — Speaker



- Remove all 4 of the 7.0mm screws and the 3 silver, smaller 4.0mm screws inside the cavity of the battery


Step 2





- Gently lift the plastic panel on the top of the laptop at the divide until the two ribbon cables and cable leads are visible with their ports on left side on laptop.

Step 3



- Gently pull on the 2 ribbon cables until they detach from the computer.
- Unplug cables connecting the top keyboard assembly and computer body.
- ⚠ Be careful not to rip the speaker cables.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-07 01:15:06 PM.